

Access4U[®] Access for Living *Instructions Stairs*

Important:

-Platform must be installed and leveled before attempting stair assembly installation

-To minimized installation time in the field, stairs are preassembled and set to the height ordered.

-Top step of the stair assembly is the first step down from the platform.


-The “L” brackets provided with the stair assembly must be used to attach the assembly to the platform.

Once the platform is positioned and level.

Position the stair assembly with platform, sidewalk and/or other features.

Insert the two lower (starter) legs into the upright posts

Insert the two longer legs into the H Frame attach the foot (similar to the ramp foot).

-Adjust the lower and upper legs so that the distance from the platform to the top step is the same as the distance from the bottom step to the ground 



Platform

H Frame
Starter Foot

Foot for Top



Post

Attach the steps to the Platform vertical section just underneath the top using the “L” Bracket



Handrail assembly is similar to the assembly of ramp handrails. As Shown



Tighten everything!



Congratulations!